


# 2018

Ubicuo Technologies

V1.4



## [ PIC TKIT USER MANUAL ]

PIC TKIT trainer kit is an advanced level trainer kit developed by Ubicuo Technologies, a GEOES INDIA venture. The kit is mainly focused on real embedded system enthusiasts who are interested in learning how basic things work in this area. We strongly recommend this kit for those who are interested in learning from scratch.

The Kit is equipped with PIC16F887 microcontroller which is an upgraded version with more features than its predecessor, can help acquire the basics of this field, similar to the role of a bicycle in helping to gain balance before moving on to bigger bikes. In this version, we have tried to include almost all basic interfacing techniques. Due to the hardware limitations of this controller, we have used several multiplexing techniques to accommodate maximum interfaces.

This user manual will guide you through the setup process during the development stages.


For support, mail to us at : [support@ubicuo.in](mailto:support@ubicuo.in)

## PIC KIT USER MANUAL


### Table of Contents

1. Board Layouts & Placements .....	3
2. LCD Interfacing (In 4-bit Mode) .....	5
3. 4-Digit , 7 SEGMENT LED Common Anode display .....	6
4. STEPPER MOTOR .....	7
5. MATRIX KEYPAD .....	8
6. SHIFT REGISTER ( Serial In Parallel Out, with Latch ) .....	9
7. LED on GPIO pin .....	10
8. Buzzer on GPIO pin .....	11
9. Relay on GPIO pin .....	11
10. Micro tact Switches .....	12
11. I2C Protocol Based Communication (RTC and EEPROM) .....	13
12. ADC 0808 8BIT ADC WITH CLOCK CIRCUIT .....	13
13. SPI based 12-bit ADC interface MCP3202 .....	14
14. SERIAL COMMUNICATION (Multiplexed) .....	15

## 1. Board Layouts



## 16x2 CHAR LCD IN 4 BIT MODE




## **PIC TKIT USER MANUAL**

## 2. LCD Interfacing (In 4-bit Mode)

- The **Port 0** will connect to the **LCD module pins** only when both the **DISP\_SEL (pin 6)** and **P0\_SEL (pin 5)** of the **SELECTION SWITCH 3** is in the **ON position**.






## Microcontroller Unit 16x2 Char LCD(4bit)



The above image shows the corresponding PIC's PORTD pins routed through the to the LCD in 4-bit mode.

### 3. 4-Digit , 7 SEGMENT LED Common Anode display


- The **Port D** will connect to the **7 SEGMENT LED** module's segment pins only when the **SELECTION SWITCH 3 , DISP\_SEL (pin 6)** is in **OFF** and **P0\_SEL (pin 5)** is in **ON** state.
- The **Switch 1,2,3,4** (DISP1, DISP2, DISP3, DISP4) must be **ON** and **5,6,7,8** (MD1, MD2, MD3, MD4) must be **OFF**, of the **SELECTION SWITCH 2**.



## PIC TKIT USER MANUAL


### 4. STEPPER MOTOR

- The stepper motor works when the **Switch 1,2,3,4** (DISP1, DISP2, DISP3, DISP4) is in **OFF** & **5,6,7,8** (MD1,MD2,MD3,MD4) is in **ON**, in **SELECTION SWITCH 2**.
- **Switch 7, 8** of the **SELECTION SWITCH 3** must be in **ON State**.



(IF CCP2(RC1) is used then Pin 5 in OFF)


SEL\_SW2




To Disable L293D Driver

SEL\_SW3

Microcontroller Unit




Stepper/DC Motor Driver



## PIC TKIT USER MANUAL


### 5. MATRIX KEYPAD

- The matrix keypad is connected to the PORT 2 pins & its recommend to keep all the switches of the **SELECTION SWITCH 2** in **OFF state**.




4\*4 MATRIX KEYPAD Lay Out

## Microcontroller Unit




## 4x4 Matrix Keypad




## 6. SHIFT REGISTER ( Serial In Parallel Out, with Latch )

- For the port expansion technique, a 74595 shift register is interfaced to the PORT1 pins. It works only when **Switch 5,6,7,8** is in **OFF state** and **1,2,3,4** is in **ON state**, of the **SELECTION SWITCH 1**.




SEL SW1



## PIC TKIT USER MANUAL


### 7. LED on PORT pin

- The LED become ON when the **Switch 1,2,3,4** is in **OFF state** and **5,6,7,8** is in the **ON state**, of the **SELECTION SWITCH 1**.



SEL\_SW1



## Microcontroller Unit



## PIC TKIT USER MANUAL

### 8. BUZZER on GPIO pin


- The **buzzer** will become **ON** only when the **Switch 3** of the **SELECTION SWITCH 2** become **ON**.



**SEL\_SW3**

### 9. RELAY on GPIO pin


- The **Relay** will become **ON** only when the **Switch 4** of the **SELECTION SWITCH 2** become **ON**



## PIC TKIT USER MANUAL



### 10. SWITCH

- The SWITCH 3 and SWITCH 4 work only when the switch 3, 4 must be OFF and switch 1, 2 must be ON, of the SELECTION SWITCH 3.



SEL\_SW3


## Microcontroller Unit      Tact Switches



## **PIC TKIT USER MANUAL**


## 11. I2C Protocol Based Communication

## The I2C Protocol Based Communication includes RTC and EEPROM




## 12. ADC 0808 8-BIT ADC WITH CLOCK CIRCUIT


## Microcontroller Unit



## 8-Bit ADC with Clock Circuit



### 13. SPI based 12-bit ADC interface (Optional )



Due to non availability and higher cost, this IC may not be populated on the PCB. Later user can insert the IC to the specified base , according to the requirement.


## PIC TKIT USER MANUAL

### 14. SERIAL COMMUNICATION

The board is supported with various mode of communications that utilizes the UART module. The modes are selected using the SEL\_SW4. Only any one of the following mode of communication can be selected at time.

#### TTL UART or RC7 & RC6 as GPIO


In this case the UART multiplexing is disabled and the pins can be connector.




SER\_SEL -8  
 SER\_B -7  
 SER\_A -6

SEL\_SW4 (SERIAL MUX is Disabled)


#### RS232



#### 433MHz Wireless Module



#### Zigbee & Bluetooth Modules



#### USB Communication

